

BKT4853-242



# VINTAGE

== Auto Garage ==



Ford Mercury 1949 Car and 48-53 Truck Flathead Alternator Mount used with **5/8" wide belt/pulley applications**

Install the alternator to the front of the bracket using the 1 1/8" spacer on the opposite side of the alternator boss to take up the difference. Use the hardware provided with the bracket. The fan bracket mounts to the front of the bracket using the existing bolts to fasten. Slide the bracket up to tighten the belt. It should be tight enough so the belt does not slip on the alternator pulley.

