





Fits 1952-1964 Ford OHV 6 and Y block V-8 engines

Will not fit Ford Thunderbird Y blocks; install bracket BKT5557TF Will not fit Lincoln Long case alternators; install bracket A200

The long portion of the adapter bracket fits onto the existing Ford generator engine mount. Mount the new bracket to the engine mount using the same hardware that held the old generator to the engine mount.

Install the alternator using the hardware provided. There is no need to over tighten the alternator bolt; the alternator should have some movement.

Install the existing belt tension arm onto the alternator and adjust the belt tension. The belt should be tight enough that it does not slip. In some cases, the tension arm may need to be modified to fit. We do not supply the tension arms.

Bracket Includes:

BOLT 5/16-18 x 1	1
BOLT M8 x 1.25 x 25mm	1
BOLT 3/8-16 x 3	1
NUT 3/8-16 NYLOCK	1
USS FLAT WASHER 1/4"	1
USS FLAT WASHER 5/16"	1
SPLIT LOCK WASHER 5/16"	1

