

Vintage Auto Garage  
800-516-4461  
info@vintageautogarage.com



## Ford Flathead V8 Timing Covers

Red cover shows spacer needed for long cam shafts  
Long cam 7/16" / Short cam 7/8" measured from the face of timing cover to the surface of the cam. If long cam need to order spacer PN 9104248 If short cam need extension button PN: 91012710

Blue covers show 2 bolts to 3 bolt adapters when installing Crab Style distributor to 3 bolt timing cover PN 9103241