


FORD, LINCOLN & MERCURY

| APPLICATION / COVERAGE | UNIT # | O.E. # | PINION GEAR TEETH / OD | NOTES (1) (2) | |
|---|--------|---|---------------------------|--|---|
| | | | | (1) ENGINE MOUNT D - DRIVERS SIDE P - PASS. SIDE | (2) DRIVE TYPE C - CENTRIFUGAL F - FOOT PEDEL S - SOLENOID |
| CALL (530) 903-0429 | | | | | |
| FORD Model A | | | | | |
| 1928-1931 | 3100GR | A11002B,C, B11002 | 10/39.4 | A: | C |
| FORD CARS & TRUCKS M/T | | | | | |
| 1932-1955 Flat Head | 3103GR | 18-11002, 7HA-11002 A11002C, FAD-11002A FAF-11001A | 10/39.4 | A: | C |
| FORD CARS & TRUCKS A/T | | | | | |
| 1951-1953 6 & 8 Cyl. | 3108GR | 1CM, FAE-11002A, FAG, FAJ-11001D, 11002B, G | 9 / 29 | A: | C |
| FORD CARS & TRUCKS M/T | | | | | |
| 1954-1955 6 & 8 Cyl. | 3115GR | B5A-11002A C3NF-11002D FAC-11001,B,G,H,M,P FAG-11002G, M | 9 / 29 | A: | C |
| 1956-1964 6 & 8 Cyl. (12V) (With 29mm O.D. Pinion Gear ONLY) | 3115GR | B6A-11002A C3NF-11002E FAR-11001A, 2A C2AZ-11001A, 2A | 9 / 29 | A: | C |
| FORD TRUCKS A/T | | | | | |
| 1952-1953 6 & 8 Cyl. | 3108GR | 1CM, FAE-11002A FAG, FAJ-11001D 11002B, G | 9 / 29 | A: | C |

A.) Bell Housing Mounting Surface to Flywheel.




B.) Starter Mounting Surface to End of Gear Teeth.

FORD, LINCOLN & MERCURY

| APPLICATION / COVERAGE | UNIT # | O.E. # | PINION GEAR TEETH / OD | NOTES (1) (2) | |
|----------------------------|--------|--|---------------------------|--|---|
| | | | | (1) ENGINE MOUNT D - DRIVERS SIDE P - PASS. SIDE | (2) DRIVE TYPE C - CENTRIFUGAL F - FOOT PEDEL S - SOLENOID |
| CALL (530) 903-0429 | | | | | |
| LINCOLN CONTINENTAL | | | | | |
| 1949-1951 ALL | 3104GR | 7EH-11002B | | A: | C |
| 1952-1959 (12V) | 3115GR | B6A-11002A C3NF-11002E FAR-11001A, 2A FAY-11002A | 9/29 | A: | C |
| MERCURY M/T | | | | | |
| 1932-1953 Flat Head | 3103GR | 18-11002 7HA-11002 A-11002C FAD-11002A FAF-11002A | 10/39.4 | A: | C |
| MERCURY A/T | | | | | |
| 1952-1953 | 3108GR | 1CM, FAE-11002A FAG, FAJ-11001D 11002B, G | 9/29 | A: | C |

A.) Bell Housing Mounting Surface to Flywheel.



B.) Starter Mounting Surface to End of Gear Teeth.

