

VINTAGE

== Auto Garage ==

Determine the “A” dimension for starter pinion gear clearance by measuring the distance from the starter mounting flange to the flywheel teeth. In the image below the “A” dimension is 1”

